

SPLIT CASE PUMPS REPLACEMENT PARTS GUIDE

PACO Split Case Kits are arranged so that you can replace virtually any component with minimum of effort.

Here are some guidelines and suggestions:

GENERAL NOTES: The pump nameplate contains all data required in the selection and ordering of the proper replacement parts kit. The pump model and serial number should be referenced whenever any replacement parts kit is ordered, while the pump conditions (GPM/TDH) and impeller trim are required data for the ordering of replacement impellers.

To replace a mechanical seal.

Select the correct Seal Kit, (which contains a complete Gasket Kit and a Bearing Kit) which will maximize seal life and eliminate future down time. Shaft sleeve inspection is suggested, and replacement made as indicated.

To replace the packing.

A Packing Kit is needed. (Again, Bearing and Gasket Kits are included.) Shaft sleeve inspection is recommended. If packing glands are damaged, they may be replaced by ordering the proper Packing Gland Kit.

To replace the shaft sleeves.

You will need a Shaft Sleeve Kit. A Seal or Packing Kit will provide all other normally needed parts.

To replace bearings.

A Bearing Kit is required and a Gasket Kit is recommended. Bearing Kits and Gasket Kits are included in Seal/Packing Kits.

To replace case wear rings.

A Case Wear Ring Kit is required. A Seal/Packing Kit will provide all other normally replaced components.

To replace impeller.

An Impeller Kit is required; a Case Wear Ring Kit is highly recommended, and a Seal or Packing Kit will provide all other normally replaced components.

To replace the shaft.

The correct shaft should be selected. Shaft replacement is most often accompanied by replacement of the seal/packing and sleeves.

To inspect the pump internals.

Since gaskets are often damaged, a Gasket Kit is recommended.

To replace lost/damaged hardware.

Hardware Kits are available, for 175 PSI units. (For 250 PSI refer to factory).

To overhaul the pump.

(Replace Rotating Assembly.) You will need an Impeller Kit, a Wear Ring Kit, a Shaft Sleeve Kit, a Seal/Packing Kit and a shaft.

NOTE:

Seal/Packing Kits are always recommended as spare parts.

**SPLIT CASE PUMPS
 REPLACEMENT PARTS GUIDE**

Model	Constr Code	KPV Lower Sleeve Kits
3014-5	X4	97668944
3014-6	X4	97668945
4012-1	X4	97668944
4012-2	X4	97668945
4012-7	X4	97668944
4012-8	X4	97668945
4015-5	X4	97668944
4015-6	X4	97668945
4015-7	X4	97668944
4015-8	X4	97668945
5012-5	X4	97668946
5012-6	X4	97668947
6012-1	X4	97668946
6012-2	X4	97668947
5012-7	X4	97668948
5012-8	X4	97668949
5015-9	X4	97668950
5015-0	X4	97668951
6012-3	X4	97668950
6012-4	X4	97668951
6019-7	X5	97668952
6019-8	X5	97668953
6015-1	X5	97668954
6015-2	X5	97668955
8012-5	X5	97668954
8012-6	X5	97668955
8015-3	X5	97668956
8015-4	X5	97668957
1012-9	X5	97668958
1012-0	X5	97668959
3095-7	XE	97668961
3095-8	XE	97668962
3095-7	X2	97668963
3095-8	X2	97668964
2013-5	X2	97668963
2013-6	X2	97668964
2095-1	X2	97668963
2095-2	X2	97668964
1015-3	X7	98129178
1015-4	X7	98129179

SPLIT CASE PUMPS REPLACEMENT PARTS GUIDE

EXPLANATION OF PUMP CODING (REFER TO PUMP NAMEPLATE)

XX	-	XXXXX	-	XXXXXX
PRODUCT CODE		MODEL NUMBER		CONSTRUCTION CODE

While PACO Split Case Pumps are designed and built to provide maximum life while requiring minimum attention and service, replacement parts may at times be required. **VIRTUALLY ALL REQUIRED PARTS ARE AVAILABLE IN KIT FORM.**

These kits (easily selected from the charts on the preceding pages) have been designed to insure that any part needed when replacing any split case component is furnished when you need it.

KIT COMPONENTS

SEAL KIT:

Mechanical Seals
Gasket Kit
Bearing Kit

PACKING KIT:

Packing Set
Lantern Rings
Retaining Rings
Gasket Kit
Bearing Kit

GASKET KIT:

Case Gasket
Seal HSG. Gaskets
Brg. Cap Gaskets
Slingers

BEARING KIT:

Bearings
Support Washers
Retaining Rings

PACKING GLAND KIT:

Packing Glands
Studs
Nuts

HARDWARE KIT:

Capscrews
Roll Pins
Nuts

WEAR RING KIT:

Wear Rings
Roll Pins
Snap Rings

IMPELLER KIT:

Bronze or Iron Impeller
Impeller Key
Coupling Key

SLEEVE KIT:

Inboard Sleeve
Outboard Sleeve
Sleeve Gaskets
Locking Collars
(where applicable)

**SHAFTS:
(non-kitted)**

Steel or Stainless
Packed or Seal

SLEEVE BEARING KIT:

Shaft	LH sleeve
Gasket Kit	Lower Sleeve
Bearing	Slinger
Bearing Housing	
Mechanical Seal	

NOTE: Kits may not contain all parts listed. They are individually selected for each pump and its construction.