


# Iwaki

## Electromagnetic Metering Pump

---

### EWP-L (North America)

---



## Instruction manual

Thank you for choosing our product.



Please read through this instruction manual before use.

This instruction manual describes important precautions and instructions for the product. Always keep it on hand for quick reference.



Veuillez lire attentivement ce mode d'emploi avant toute utilisation.

Ce manuel d'instructions décrit les précautions et instructions importantes pour le produit. Gardez-le toujours à portée de main pour consultation rapide.

## Order confirmation

Open the package and check that the product conforms to your order. If any problem or inconsistency is found, immediately contact your distributor.

### a. Check if the delivery is correct

Check the nameplate to see if the information such as model codes, discharge capacity and discharge pressure are as ordered.

Iwaki Metering Pump		FREQUENCY	Hz
MODEL		MFG.No.	
PRESSURE	PSI	Year	
CAPACITY	GPH	Thermal Protected Acceptable for indoor use only Enclosure type 2	
VOLTAGE	V	Utilization intérieure uniquement Billets de type 2	
CURRENT	A	Nonsubmersible Pump Certified to ANSI 31.50, Sec.11.6	
<b>IWAKI CO., LTD.</b> HEAD OFFICE 1-6-10, Kanda-Subsidiary 2-chome, Chiyoda-ku, Tokyo, Japan		<b>IP66</b> Certified to CAN/CSA S52.02.2 No.108	<b>Intertek</b> 3111327 <b>PM16-2</b>

### b. Check accessories are complete



A 3mm or 4mm hex wrench



Two baseplates  
(SH type)

### c. Check if the delivery is damaged or deformed

Check for transit damage and loose bolts.

# Contents

Order confirmation.....	2
-------------------------	---

## **Safety instructions/Consignes de sécurité .....6**

WARNING / AVERTISSEMENT .....	8
-------------------------------	---

CAUTION / ATTENTION.....	10
--------------------------	----

Precautions for use / Précautions d'utilisation .....	14
---	----

## **Overview..... 18**

Introduction .....	18
--------------------	----

Pump structure & Operating principle .....	18
--	----

Features.....	19
---------------	----

Part names .....	20
------------------	----

Pump.....	20
-----------	----

Operational panel .....	21
-------------------------	----

Identification codes .....	22
----------------------------	----

Pump.....	22
-----------	----

Operational functions .....	24
-----------------------------	----

Manual mode .....	24
-------------------	----

EXT mode.....	24
---------------	----

■ Analog proportional control (ANA) .....	24
---	----

■ Pulse synchronous control (PLS) .....	24
---	----

STOP functions.....	25
---------------------	----

## **Installation .....26**

Pump mounting .....	26
---------------------	----

Plumbing .....	28
----------------	----

Tube connection .....	28
-----------------------	----

Thread connection.....	30
------------------------	----

Check valve/Back pressure valve mounting.....	31
---	----

Wiring .....	33
--------------	----

End terminals .....	33
Power voltage/Earthing .....	34
■ Pump with the "US" or "UH" power plug codes.....	34
Signal wire connection.....	36
■ EXT IN .....	38

## **Operation.....39**

<b>Before operation.....</b>	<b>39</b>
Points to be checked .....	39
Retightening of head bolts.....	39
■ Use of hex wrench instead of a torque wrench .....	40
Degassing.....	41
■ EWP VC/VS/VE/PC/PS/PE/TC/SH with the MAN air vent port.....	41
■ EWP FC with no MAN air vent port .....	43
Flow rate adjustment .....	44
■ Stroke rate adjustment.....	46
■ Stroke length adjustment.....	47
Before a long period of stoppage (one month or more).....	48
<b>Operation setting .....</b>	<b>48</b>
Manual operation.....	48
EXT operation.....	49
■ Analog proportional control .....	49
■ Pulse synchronous control .....	49
Control functions.....	50
■ STOP function .....	50

## **Maintenance.....51**

<b>Troubleshooting .....</b>	<b>52</b>
<b>Inspection .....</b>	<b>53</b>
Daily inspection .....	53
Periodic inspection .....	53
<b>Wear part replacement .....</b>	<b>54</b>

Wear part list.....	54
Before replacement .....	55
Valve set replacement .....	55
■ Discharge valve set disassembly/assembly .....	55
■ Suction valve set disassembly/assembly .....	60
Diaphragm replacement .....	61
<b>Exploded view .....</b>	<b>64</b>
Pump head, Drive unit & Control unit .....	64
Pump head .....	65
■ EWP-038B/-130D/-270E/-410F/-420F VC/VS/VE/PC/PS/PE/TC.....	65
■ EWP-038B/-080C/-130D/-270E/-410F FC .....	66
■ EWP-038B/-080C/-130D/-270E/-410F SH .....	67
<b>Specifications/Outer dimensions.....</b>	<b>68</b>
Specifications .....	68
■ Pump unit.....	68
■ Control unit .....	69
■ Power cable .....	69
■ Pump color.....	69
Outer dimensions.....	70
■ EWP-038B/-080C/-130D/-270E/-410F/-420F VC/VS/VE/PC/PS/PE/TC.....	70
■ EWP-038B/-080C/-130D/-270E/-410F FC .....	71
■ EWP-038B/-080C/-130D/-270E/-410F SH .....	72

# ***Safety instructions/Consignes de sécurité***

***Read through this section before use. This section describes important information for you to prevent personal injury or property damage.***

***Veillez lire attentivement cette section avant toute utilisation. Elle fournit d'importantes informations visant à empêcher toute blessure corporelle ou tout dommage matériel.***

## **■ Symbols / Symboles**

In this instruction manual, the degree of risk caused by incorrect use is noted with the following symbols. Please pay attention to the information associated with the symbols.

Dans le présent manuel d'instructions, le degré de risque lié à une utilisation incorrecte de l'équipement est indiqué par les symboles suivants. Veuillez prêter attention aux informations associées à chaque symbole.

### **WARNING**

Indicates mishandling could lead to a fatal or serious injury accident.

### **AVERTISSEMENT**

Indique que toute erreur de manipulation peut conduire à un accident entraînant de graves blessures corporelles ou la mort.

### **CAUTION**








Indicates mishandling could lead to personal injury or property damage.

### **ATTENTION**

Indique que toute erreur de manipulation peut conduire à des blessures corporelles ou à des dommages matériels.

A symbol accompanies each precaution, suggesting the use of "Caution", "Prohibited actions" or specific "Requirements".

Chaque mesure de sécurité est accompagnée d'un symbole, qui indique un "Avertissement", des "Actions interdites" ou une "Exigence" particulière.

Caution marks / Symbole d'avertissement		Prohibited marks / Symbole d'interdiction		Requirement marks / Symbole d'exigence		
						
Caution	Electrical shock	Prohibition	Do not remodel	Requirement	Wear protectors	Grounding
Attention	Électrocution	Interdiction	Ne pas remanier	Exigence	Porter des EPI	Mise à la terre

### **Export Restrictions / Restrictions à l'exportation**

Technical information contained in this instruction manual might be treated as controlled technology in your countries, due to agreements in international regime for export control.

Please be reminded that export license/permission could be required when this manual is provided, due to export control regulations of your country.

Les informations techniques contenues dans le présent manuel d'instructions peuvent être considérées dans vos pays comme une technologie contrôlée, en raison d'accords dans le cadre du régime international pour le contrôle des exportations.

Veuillez garder à l'esprit qu'un permis/une licence d'exportation peut être nécessaire pour la fourniture du présent manuel d'instructions, en raison de la réglementation relative au contrôle des exportations de votre pays.

## **WARNING / AVERTISSEMENT**

### **Turn off power before service**

Risk of electrical shock. Be sure to turn off power to stop the pump and related devices before service is performed.

### **Couper l'alimentation électrique de la pompe avant intervention**

Intervenir sur la pompe sans avoir au préalable coupé l'alimentation électrique peut déclencher des décharges électriques. Avant d'entreprendre n'importe quel type d'intervention, veillez à mettre la pompe et tout dispositif connexe hors tension à l'aide de l'interrupteur prévu à cet effet.



### **Stop operation**

If you notice any abnormal or dangerous conditions, suspend operation immediately and inspect/solve problems.

### **Arrêter le fonctionnement**

Si vous détectez une anomalie ou des signes suspects et inhabituels pendant le fonctionnement, interrompez immédiatement les opérations et inspectez, résolvez les problèmes.



### **Do not use the pump in any condition other than its intended purpose**

The use of the pump in any conditions other than those clearly specified may result in failure or injury. Use this product in specified conditions only.

### **Se conformer uniquement aux applications prévues**

La pompe doit être utilisée conformément à l'usage pour lequel elle a été prévue et dans le respect de ses caractéristiques techniques. Toute utilisation non conforme peut entraîner un incident ou endommager le dispositif.



### **Do not modify the pump**

Alterations to the pump carries a high degree of risk. It is not the manufacturer's responsibility for any failure or injury resulting from alterations to the pump.

### **Ne pas modifier la pompe**

Ne jamais modifier une pompe sous peine de causer un incident grave. Iwaki ne pourra en aucun cas être tenu responsable d'un incident ou de dégâts survenus à la suite d'une modification du dispositif.



---

### Wear protective clothing

Always wear protective clothing such as an eye protection, chemical resistant gloves, a mask and a face shield during disassembly, assembly or maintenance work. The specific solution will dictate the degree of protection. Refer to SDS precautions from the solution supplier.



Wear  
protectors  
Porter des EPI

### Porter un équipement de protection

Toujours porter un équipement de protection (lunettes, gants résistants aux produits chimiques, masque, casque) durant le démontage, l'assemblage et la maintenance.

Le travail effectué dictera le degré de protection. Référez-vous au SDS de la solution proposée par le fournisseur.

---

### Do not damage the power cable

Do not pull, knot, or crush the power cable. Damage to the power cable could lead to a fire or electrical shock if cut or broken.



Prohibition  
Interdiction

### Ne pas endommager le câble électrique

Ne pas tirer ou faire un nœud avec le câble électrique. Endommager un câble électrique peut provoquer un incendie ou une décharge électrique.

---

### Do not operate the pump in a flammable atmosphere

Do not place explosive or flammable material near the pump.



Prohibition  
Interdiction

### Ne pas utiliser la pompe dans une atmosphère explosive

Pour votre sécurité, du matériel dangereux ou inflammable ne doit pas être placé près de la pompe.

---

### Risk of electric shock

This pump is supplied with a grounding conductor and ground-ing-type attachment plug. To reduce the risk of electric shock, be certain that it is connected only to a properly grounded, grounding type receptacle.



Prohibition  
Interdiction

### Risque de choc électrique

La pompe est fournie avec un conducteur pour mise à la terre et une prise courant. Afin de réduire le risque de choc électrique, veillez à ce que la terre soit correctement raccordée.

### Qualified personnel only

The pump should be handled or operated by qualified personnel with a full understanding of the pump. Any person not familiar with the product should not take part in the operation or maintenance of the pump.

### Opérateur qualifié uniquement

La pompe doit être manipulée ou utilisée par du personnel qualifié connaissant parfaitement la pompe. Tout autre personne étrangère ne doit pas prendre part à l'utilisation ou à la maintenance de la pompe.



Requirement  
Exigence

### Use specified power only

Do not apply power other than that specified on the nameplate. Otherwise, failure or fire may result. Ensure the pump is properly grounded.

### Utilisez une tension appropriée uniquement

Ne pas appliquer une autre tension que celle spécifiée sur la plaque signalétique sinon, il peut en résulter une panne ou une incendie. Assurez-vous également de la mise à la terre de la pompe.



Prohibition  
Interdiction

### Do not run pump dry

Do not run pump dry for more than 30 minutes (even when the pump runs for degassing). Otherwise, the pump head fixing screws may loosen and liquid may leak. Optimize your system. If the pump runs dry for a long period (for more than 30 minutes), the pump head and the valve cases may deform by friction heat and consequently leakage results.

### Ne faite pas fonctionner la pompe à sec

Ne faite pas fonctionner la pompe à sec plus de 30 minutes (même lorsque la pompe fonctionne pour dégazer). Sinon, les visse de fixation de la tête peuvent se dévisser et il peut y avoir une fuite de liquide. Optimalisez l'installation de façon à ce que la pompe ne fonctionne pas à sec. Si la pompe fonctionne à sec pour une longue période (plus de 30 minutes), la tête de la pompe et le guide de clapets peuvent être déformés par friction causée par la chaleur et il en résulterait des fuites.



Caution  
Attention

**Keep electric parts and wiring dry**

Risk of fire or electric shock. Install the pump where it can be kept dry.

**Ne mouillez pas les parties électriques ou les câbles**

Risque d'incendie ou de décharge électrique. Installez la pompe dans un endroit sec.



Prohibition  
Interdiction

**Ventilation**

Fumes or vapors can be hazardous with certain solutions. Ensure proper ventilation at the operation site.

**Ventilation**

Manipuler un produit toxique ou odorant peut provoquer une intoxication. Prévoyez une ventilation suffisante à l'endroit de la manipulation.



Caution  
Attention

**Do not install or store the pump:**

- In a flammable atmosphere.
- In a dusty/humid environment.
- Where ambient temperature can exceed 32-104°F (0-40°C).
- In direct sunlight or wind & rain.

**N'installez ou ne stockez pas la pompe dans les endroits suivantes:**

- Dans une atmosphère inflammable
- Dans un endroit poussiéreux ou humide.
- Dans une place où la température n'est pas comprise entre 0 et 40 °C.
- Directement sous le soleil, le vent ou la pluie.



Prohibition  
Interdiction

**Spill precautions**

Ensure protection and containment of solution in the event of plumbing or pump damage (secondary containment).

**Déversement accidentel**

Prenez des mesures protectrices contre tout incident résultant d'un débit trop important de la pompe ou d'une casse de tuyauterie.



Requirement  
Exigence

---

## Do not use the pump in a wet location

The pump is not waterproof. Use of the pump in wet or extremely humid locations could lead to electric shock or short circuit.



Prohibition  
Interdiction

## N'utilisez pas la pompe sous l'eau

La pompe n'est pas complètement étanche. Utiliser la pompe dans l'eau ou dans un endroit très humide peut créer une décharge électrique ou un court-circuit.

---

## Grounding

Risk of electrical shock! Always properly ground the pump. Conform to local electric codes.



Grounding  
Mise à la terre

## Mise à la terre

Veillez à ne pas faire fonctionner la pompe sans avoir au préalable prévu une mise à la terre. Celle-ci permettra d'éviter d'éventuelles décharges électriques. Vérifiez que le câble de mise à la terre est bien branché.

---

## Install a GFCI (earth leakage breaker)

An electrical failure of the pump may adversely affect other devices on the same line. Purchase and install a GFCI (earth leakage breaker) separately.



Electrical  
shock  
Électrocution

## Détecteur de fuites à la terre

Un problème électrique peut affecter défavorablement le dispositif. Achetez et installez un détecteur de fuites à la terre.

---

## Preventative maintenance

Follow instructions in this manual for replacement of wear parts. Do not disassemble the pump beyond the extent of the instructions.



Requirement  
Exigence

## Remplacement des pièces usées

Suivez les instructions de ce manuel pour remplacer les pièces usées. Ne démontez pas la pompe au-delà des instructions.

---

## Do not use a damaged pump

Use of a damaged pump could lead to an electric shock or death.



Prohibition  
Interdiction

## N'utilisez pas une pompe endommagée

Utiliser une pompe endommagée peut provoquer une décharge électrique ou la mort.

## Disposal of a used pump

Dispose of any used or damaged pump in accordance with local rules and regulations. If necessary, consult a licensed industrial waste disposal company.



Requirement  
Exigence

## Elimination des pompes usées

Elle doit se faire en conformité avec les règles locales en vigueur (consultez une entreprise certifiée et spécialisée).

## Check pump head bolts

Liquid may leak if any of the pump head bolts become loose. Tighten the bolts evenly to the following torque in diagonal order before initial operation and at regular intervals.

### Tightening torque

EWP-038B/-080C/-130D/-270E	: 19 lb-in	M4 hex socket bolt
EWP-410E/-420F	: 22.6 lb-in	M5 hex socket bolt



Caution  
Attention

## Serrez la tête de pompe

La pompe peut fuiter si les boulons sont desserrés. Resserrez les boulons diagonalement et uniformément avant la première utilisation Resserrez les boulons régulièrement pour éviter tout fuite.

### Couple de serrage

EWP-038B/-080C/-130D/-270E	: 19 lb-in	M4 boulon à tête hexagonale
EWP-410E/-420F	: 22.6 lb-in	M5 boulon à tête hexagonale

## Install a relief valve

Install a relief valve on a discharge line near the pump so as to automatically release the discharge pressure when it exceeds the maximum level.

## Installer une soupape de décharge

Installez une soupape de décharge sur la conduite de refoulement à proximité de la pompe de manière à relâcher automatiquement la pression au refoulement lorsqu'elle dépasse le seuil maximal.



Requirement  
Exigence

## Precautions for use / Précautions d'utilisation

- Electrical work should be performed by a qualified electrician. Otherwise, personal injury or property damage could result.

Le raccordement électrique de la pompe doit être effectué par du personnel qualifié sinon, il pourrait y avoir un dommage corporel ou incorporel.



Caution  
Attention

- Do not install the pump:
  - In a flammable atmosphere.
  - In a dusty/humid place.
  - In direct sunlight or wind & rain.
  - Where ambient temperature can exceed 32-104°F (0-40°C).

Protect the pump with a cover when installing it out of doors.

Ne pas installer la pompe dans les endroits suivants:

- Dans une atmosphère inflammable
- Dans une atmosphère poussiéreuse ou humide.
- Sous les rayonnements du soleil, dans le vent ou sous la pluie.
- La température ambiante doit être comprise entre 0 et 40°C.

Protégez la pompe par un capot si vous l'installez dehors.



Caution  
Attention

- Select a level location, free from vibration, that won't hold liquid. Anchor the pump with four M5 bolts so it doesn't vibrate. If the pump is not installed level, output may be affected.

Choisissez un endroit où il n'y a pas de vibrations et où le liquide peut s'évacuer. Fixez la pompe à l'aide de vis M5 de façon à ne pas avoir de vibrations. Si la pompe est inclinée, le débit peut être réduit.



Requirement  
Exigence

- When two or more pumps are installed together, vibration may be significant, resulting in poor performance or failure. Select a solid foundation (concrete) and fasten anchor bolts securely to prevent vibration during operation.

Si plusieurs pompes sont installées ensemble, elles interagissent et les vibrations peuvent devenir importantes, ce qui engendre des performances médiocres ou des ratures. Choisissez un endroit solide et fixez les boulons correctement pour éviter les vibrations pendant le fonctionnement.



Requirement  
Exigence

- Allow sufficient space around the pump for easy access and maintenance.

Prévoyez de l'espace autour de la pompe pour faciliter l'accès et la maintenance.



Caution  
Attention

- Install the pump as close to the supply tank as possible.

Installez la pompe le plus près possible du tank de produit.



Requirement  
Exigence

- When handling liquids that generate gas bubbles (sodium hypochlorite or hydrazine solution), install the pump in a cool and dark place. Flooded suction installation is strongly recommended.

Installez la pompe dans une place froide à l'abri du soleil lorsqu'il s'agit du dosage de produits dégazant tels que l'hypochlorite de sodium ou l'hydrazine. Mettre la pompe en charge est vivement recommandé.



Requirement  
Exigence

- Use care handling the pump. Do not drop. An impact may affect pump performance. Do not use a pump that has been damaged to avoid the risk of electrical damage or shock.

Veillez à ne pas laisser tomber la pompe sur le sol. Un impact important pourrait réduire les performances de la pompe. Ne pas utiliser une pompe endommagée sinon il pourrait y avoir un courant de fuite ou une décharge électrique.



- The pump has a rating of IP66, but is not waterproof. Do not operate the pump while wet with solution or water. Failure or injury may result. Immediately dry off the pump if it gets wet.

Le pompe est IP66 mais n'est pas complètement étanche. Ne pas laisser la pompe couverte de liquide pompé ou sous la pluie. Il pourrait y avoir des ratés ou préjudices. Si la pompe a été mouillée, sechez-la directement.



- Do not close discharge line during operation. Solution may leak or piping may break. Install a relief valve to ensure safety and prevent damaged plumbing.

Ne fermez pas la ligne de refoulement lorsque la pompe est en fonctionnement sinon il pourrait y avoir des fuites de liquide ou la tuyauterie pourrait céder. Installez une soupape de sécurité pour des raisons de sécurité et pour éviter tout dommage de la tuyauterie.



- Solution in the discharge line may be under pressure.  
Release the pressure from the discharge line before disconnecting plumbing or disassembly of the pump to avoid solution spray.

Le liquide au refoulement peut être sous pression.  
Relâchez la pression du refoulement avant de démonter la pompe ou d'enlevez le tubage pour éviter tout jet de liquide.



Requirement  
Exigence

- Wear protective clothing when handling or working with pumps. Consult solution SDS for appropriate precautions. Do not come into contact with residual solution.

Portez un équipement de sécurité lorsque vous manipulez la pompe. Consultez le SDS pour utilisez les précautions appropriées. Evitez tout contact avec le liquide chimique.



Caution  
Attention

- Do not clean the pump or nameplate with a solvent such as benzine or thinner. This may discolor the pump or erase printing. Use a dry or damp cloth or a neutral detergent.

Ne nettoyez pas la pompe ni la plaque signalétique à l'aide d'un solvant comme du benzine ou du diluant. Cela risque de décolorer la pompe ou d'effacer des données inscrites dessus. Utilisez un chiffon sec ou humide, ou un détergent neutre.



Prohibition  
Interdiction

- This pump has been evaluated for use with water only.

Cette pompe a été testée uniquement avec de l'eau.



Caution  
Attention

# Overview

**Pump characteristics, features and part names are described in this section.**


## Introduction

### Pump structure & Operating principle

The EWP series is a diaphragm metering pump which consists of a pump head, a drive unit, and a control unit. A diaphragm is directly driven by electro-magnetic force.

#### Principle of operation

The pulse signal via the control unit generates the electromagnetic force to make reciprocating motion with the assistance of the spring force. The reciprocating motion is transferred to the diaphragm through the shaft and then volumetric change occurs in the pump head. This action transfers liquid along with pump head valve action.



## Features

---

- **Multivoltage operation**

The EWP series is a multivoltage type (100-240VAC) and can be selected without local power limitations.

- **Simple operation with just two knobs**

The front panel is simple and can be used intuitively for the stroke rate adjustment of 0 to 100% with fine flow tuning (stroke length adjustment).

- **Waterproof and dustproof structure**

The sealed unit design assures a rating of IP66.

\*Protect the pump with a cover when installing it out of doors.

- **Two control modes**



The analog proportional control mode and the pulse synchronous control mode regulate your pump corresponding to the external signal from your device.

- **Highly-efficient solenoid**



Realizes higher energy saving and downsizing than ever before.

# Part names


## Pump



Pumps with SH/FC wet ends



## Operational panel



## Identification codes

The model codes of the pump represents the following information.

### **Pump**

#### **EWP - 038B VC 01 N - US L**

**a          b          c          d          e          f          g**

##### **a. Series name**

EWP: Multivoltage electromagnetic metering pump

##### **b. Pump unit**

	Pump Capacity	Pump Head Code	Capacity		Pressure	
			mL/Min	GPH	MPa	PSI
Standard Models	025	A	25	0.4	1.2	175
	045	B	45	0.7	1.0	150
	075	C	75	1.2	0.7	105
	125	D	125	2.0	0.4	60
	265	E	265	4.2	0.2	30
	080	C	80	1.3	1.0	150
	130	D	130	2.0	0.7	105
	270	E	270	4.3	0.35	50
	420	F	420	6.7	0.2	30
	420*1	F	410	6.5	0.2	30
Auto-Degassing Valve	035	B	35	0.6	1.0	150
	055	C	55	0.9	0.7	105
	085	D	85	1.4	0.4	60
	064	C	64	1.0	1.0	150
	110	D	110	1.7	0.7	105

\*1 TA/TC/FC/SH only

### c. Wet end materials

Code	Pump Head	Valve Balls	Valve Seat	O-ring	Gasket	Diaphragm
VC	PVC	CE	FKM	FKM	PTFE	PCTFE (bonded to EPDM)
VE			EPDM	EPDM		
VF		PTFE				
PC	GFRPP	CE	FKM	FKM		
PE			EPDM	EPDM		
PA			PCTFE	AFLAS		
TC			FKM	FKM		
TA	PVDF		PCTFE	AFLAS		
FC						
SH	316SS	HC	316SS	—		

#### Material code

CE	Alumina ceramic	GFRPP	Glassfiber-reinforced polypropylene
FKM	Fluorine-contained rubber	PVC	Polyvinyl chloride
PTFE	Polytetrafluoroethylene	HC	Hastelloy C-276 equivalent
PVDF	Polyvinylidene difluoride	316SS	Stainless Steel
EPDM	Ethylene-propylene rubber	AFLAS	Ethylene propylene diene monomer

### d. Connection

Code	Tube I.D. × O.D.	Wet ends	Pump type
07	ø1/4"×ø3/8"	VC/VE/PC/PA/PE/TC/TA/FC	A/B/C/D
08	ø3/8"×ø1/2"		E/F
10	1/4" FNPT	SH	B/C/D/E/F
11	1/2" MNPT	PC/PS (HV only)	E

### e. Special Options:

N: No special options



A: Auto Degassing Valve (available on B/C/D sizes-VC/VE)

F: 1st Generation AAVV Installed (derates pressure by 40PSI)

K: No Manual Air Valve (SH models only)

M: Multi Function Valve (N/A on FC/SH or with other options)

### f. Voltage/Power Cord/Plug

Code	Area	Power plug	Cable length
US	USA (115VAC)		78.74" (2000mm)
UH	USA (230VAC)		

### g. Controller

L: Simple function

– Speed Control (knob)

– Stroke Length adjustment

– 1:1 Digital Input / 4-20 Input / STOP Input Control

## **Manual mode**

---


The pump doesn't have an ON-OFF switch. Supplying the rated voltage to the pump starts operation (the ON LED lights up). Discontinuing the voltage supply stops operation (the ON LED goes off).

## **EXT mode**

---

### ■ Analog proportional control (ANA)


The pump increases/decreases strokes in proportion to the incoming 4-20mA current signal (between 0 and the maximum stroke rate of the pump that is user-settable).



### ■ Pulse synchronous control (PLS)

The pump increases/decreases strokes in sync with the incoming pulse signal (between 0 and the maximum stroke rate of the pump that is user-settable).

\*The pump does not run exceeding the 360spm at any pulse rate.




## STOP functions

---

The start/stop of the pump can be controlled by external devices such as a level sensor.

The pump stops while receiving the external signal via the STOP terminal (normally-open contact).

\*Opening the STOP circuit resumes pump operation.



The pump stops running while the STOP signal is inputted.

# Installation

***This section describes the installation of the pump, tubing and wiring. Read through this section before work.***

## **!** Points to be Observed

- Risk of electrical shock. Be sure to turn off power to stop the pump and related devices before service is performed.
- If you notice any abnormal or dangerous conditions, suspend operation immediately and inspect/solve problems.
- Do not place explosive or flammable material near the pump.
- Do not use a damaged pump. Use of a damaged pump could lead to an electric shock or death.

## Pump mounting

*Select an installation location and mount the pump.*

### Necessary tools

- Four M5 bolts (purchase separately)
- Adjustable wrench
- Two baseplates (pumps with SH wet end code)


## **1** Select a suitable place

Always select a flat floor free of vibration. See page 14 as well.

\*Flooded suction is strongly recommended, especially when pumping liquids that readily generate gas bubbles. Sodium hypochlorite and hydrogen peroxide are common examples of such liquids.


## 2 Place two baseplates on the pump (SH only)

The pump with the SH wet end code is heavier than other models. It is recommended to use optional metal baseplates (supplied separately) to reinforce the pump's base.



## 3 Use the four M5 bolts and fix the pump


Be sure to fix the base at four points.



Connect tubes to the pump and install a check valve.

### Before operation

- Cut the tube ends flat.



Tube end (side view)


### Necessary tools

- An 1.5" (38mm) or wider adjustable wrench

## Tube connection

- Pass the tube through the fitting nut and stopper, and then slide it down onto the adaptor as far as it will go.
- Put the tube end (adaptor) onto the fitting. Then hand tighten the fitting nut.
- Retighten the fitting nut by turning it further 180 degrees with an adjustable wrench so it crushes into the tube a little.

\*Do not use excessive force when tightening the plastic fitting nut.




### When the tube is removed and then reconnected

- If the fitting nut, stopper, adaptor, fitting, or tube surface is wet with a chemical liquid, flush with tap water and then dry off. Wet parts won't bite into the tube successfully, and the tube may slip out of the connection with a chemical spill.
- When removing the connection, if the adaptor has become stuck in the crushed tube and stopper and those parts can not be separated, contact us for a new adaptor/stopper set.
- Do not reuse the same crushed tube end to reseal the tubing. Cut off the end and start with new tubing to ensure a new seal is established.
- Use a new tube if the old tube is hardened, swollen, discolored, cracked, worn, or sticky.


# 1 Connect tubes into the pump inlet and outlet

\*Use the proper tube size depending on wet end materials and the pump type. See page 23.




# 2 Connect a tube to establish the air vent line

Route back the other tube end to a supply tank or a container.




# 3 Determine the air vent body A direction

- a. Loosen the lock nut.
- b. Turn the air vent body A to the optimal direction.
- c. Hand-tighten the lock nut, holding the air vent body A.
- d. Use an adjustable wrench to turn the lock nut 90° further from the hand-tightened point.




# Thread connection

- 1** Wrap a sealing tape around the threads of the discharge/ suction pipe and tighten them




- 2** Establish the air vent line

- Loosen the nut. Pass the air vent tube through the nut.
- Slide the air vent tube down into the male thread connector as far as it will go.
- Hand-tighten the nut.
- Use an adjustable wrench to turn the nut 45° further from the hand-tightened point.
- Route back the other tube end to a supply tank or a container.




## Tubing layout

Flooded suction application




Suction lift application



\*Flooded suction is strongly recommended, especially when pumping liquids that readily generate gas bubbles. Sodium hypochlorite and hydrogen peroxide are common examples of such liquids.

## NOTE


The air vent port is not provided to the EWP with FC wet ends. Purchase separately and install an external air vent valve to your piping as the right diagram shows.




## Check valve/Back pressure valve mounting

Install an optional check valve or a back pressure valve to the pump for the prevention of a back flow, siphon and overfeeding. In the following cases be sure to install the check valve.


- A suction side liquid level is higher than the discharge side.



- A suction side liquid level is lower than the discharge side but the height distance is 16.4ft (5m) or below.



- A suction line pressure is higher than a discharge line pressure.



- The back pressure to the pump (including pipe resistance and discharge head) is below 18.9PSI or 0.13MPa. (below 7.1PSI or 0.049MPa for the EWP-410F/-420F).

# 1


## Mount an optional check valve at the discharge tube end

\*The CAN check valve has the R $\frac{1}{2}$  and R $\frac{3}{8}$  thread connections as well as an O.D.9mm tube connection. If required, trim off an amount of the extension tip until it fits your fitting or tee.

### NOTE

The maximum allowable tightening torque of the R $\frac{1}{2}$  and R $\frac{3}{8}$  thread connections are 88.51 lb-in (10 N·m). Do not use excessive force when tightening into a pipe.

#### CAN check valve




\*The CBN check valve (both ends tube connections) and the BVC back pressure valve are optionally available. Contact us or your nearest distributor.

#### CBN check valve



#### BVC back pressure valve



### NOTE

- Install a relief valve on a discharge line near the pump so as to automatically release the discharge pressure when it exceeds the maximum level.
- If the set pressure of the check valve plus the injection point pressure to your system is lower than the maximum discharge pressure of the pump, the pump output can exceed the specified point. See page 44 and adjust the output capacity.


Wiring for a power voltage, earthing and an external signal.

### ! Points to be observed

- Electrical work should be performed by a qualified electrician. Always observe applicable codes or regulations.
- Observe the rated voltage range, or the electrical circuit in the control unit may fail.
- Risk of electrical shock. Be sure to turn off power to stop the pump and related devices before service is performed.
- Risk of electric shock. Replacement of the power cable should be conducted by a manufacturer, his agency or a skilled person.

## End terminals

See the following diagram for detail.



## Power voltage/Earthing

Check that the main power is turned off.

### ■ Pump with the "US" or "UH" power plug codes

#### 1 Insert the plug all the way seated in a socket


This product has two power wires and one earth wire, and is classified as class I.

\*This pump is supplied with a grounding-type attachment plug. To reduce the risk of electrical shock, be certain that it is connected only to a properly grounded, grounding type receptacle.


#### NOTE

- Do not share a power source with a high power device which may generate surge voltage. Otherwise an electronic circuit may fail. The conductive noise caused by an inverter also affects the circuit.
- Energize the pump with a power voltage via a mechanical relay or switch. Do not fluctuate the voltage, or CPU may malfunction. See page 36 for the precautions for ON-OFF control by cycling power.

#### Apply power sharply



#### Do not apply gradually




- Use a circuit protector (250VAC, 3A Medium speed) as necessary.
- Do not use a motor thermal relay.

### Surge voltage

The electronics within the pump can be damaged by excessive surges in voltage. Do not install the pump near high-power electrical equipment that generates high surge voltages. Avoid branch circuits that also supply power to heavy or other equipment that could generate electrical interference.

If necessary,

- install a surge suppression device (such as a varistor with a resistance greater than 2000A)




#### Recommended varistors

Panasonic ERZV14D431

KOA NVD14UCD430

See manufacturer's catalogs for detail.

- or a noise-reducing transformer at the pump's power connection.



Noise-reducing transformer

### **Precautions for ON-OFF control by cycling power**

The control unit is equipped with a CPU. To ensure the CPU to work properly, always start/stop the pump with the STOP signal for ON-OFF control. Try not to turn on and off the main power. Otherwise, observe the following points:

- Ensure the minimum OFF time of 10 minutes.
- When using a mechanical relay for ON-OFF operation, its contact capacity should be 5A or more. Or a contact point may break.
- If a mechanical relay with the contact capacity of 5A is used, the maximum allowable number of power cycles is limited to 150,000 times. Use the contact capacity of 10A or more when the power cycles exceed that number or when a power source is shared with a large capacity equipment which may cause a surge voltage and damage a contact point.
- Even the large mechanical relay may not last forever. If further longer life is desirable, use a SSR (Solid State Relay) such as the OMRON G3F that does not have a mechanical contact point. Note this product is not designed to be operated with a zero-crossing SSR. See manufacturer's catalogs and make sure a non zero-crossing SSR is selected.

## ***Signal wire connection***

---

### **Points to be checked**

- Check that the main power is turned off.

### **Applicable cables**

Use our optional connector cable for the EXT IN signal (or Binder 99-0436-10-05 Series 713) or purchase a 5-pin female connector cable when using signal input.

## NOTE

---

- Do not install these signal cables in parallel with a power cable. Otherwise the electromagnetic induction noise is generated and malfunction or failure may result.
- When using an external SSR for signal input, such a semiconductor relay must be capable of handling the maximum applied voltage from the pump (5V with 2.3mA). Also, its leak current must be 0.1mA or below.  
See specs of the selected SSR. The following SSRs at least meet the requirements:  
- OMRON G3TA-IDZR02S-US or G3TA-IDZR02SM-US
- When using an external mechanical relay for signal input, such a relay must be capable of handling the maximum applied voltage from the pump (5V with 2.3mA). Its minimum application load should be 1mA or less.
- Insert the DIN 5-pin female connector as far as it will go and then tighten the locking collar to make a secure connection.
- Connect the signal cables to external devices which are protected by double or reinforced insulation.

---

\*Use either an external no-voltage contact or an external open collector for the signal line wiring.

## ■ EXT IN

### Wiring diagram

To make the analog proportional control, pulse synchronous control, or to activate the STOP functions, use the EXT IN terminal via a DIN 5-pin connector.

• **When using an open collector signal from an external device to the pump:**


An open collector signal is polarity sensitive. Use the PLS IN (POSITIVE) and the COM (GND) typically for the pulse signal input.

• **When using an analog signal from the 4-20 mA signal generator:**

Polarity Sensitive. Connect the 4-20mA line to the ANA IN (positive) and COM. The input resistance is 220Ω.

• **When using a dry contact signal from an external device to the pump:**

A dry contact signal is generally not polarity sensitive. Use the STOP IN and the COM typically the stop signal input. Use a mechanical relay or switch designed for an electronic circuit. Its minimum application load should be 1mA or less.



### Pin assignment

Electrically connect the pump and you device.

Input	Terminals		EXT controls/functions
	+	-	
PLS IN	PIN 1 (Brown)	PIN 4 (Black)	Pulse synchronous control
ANA IN	PIN 2 (White)	PIN 4 (Black)	Analog proportional control
STOP IN	PIN 3 (Blue)	PIN 4 (Black)	STOP function

# Operation

***This section describes pump operation and setting.  
Run the pump after pipework and wiring are completed.***

## Before operation

*First check tubing and wiring are correct. And then perform degassing and flow rate adjustment before starting operation.*

### ***Points to be checked***

---

*Before operation, check if:*

- Liquid level in a supply tank is enough.
- Tubing is securely connected and is free from leakage and clogging.
- Discharge/suction valves are opened.
- A power voltage is in the allowable range.
- Electrical wiring is correct and is free from the risk of short circuit and electrical leakage.

### ***Retightening of head bolts***

---

#### **Important**


Head bolts may loosen when plastic parts creep due to temperature change in storage or in transit. This could lead to a chemical leak. Tighten the bolts diagonally and evenly by the rated torque at each model before initial operation and at regular intervals (every three months).

#### **Tightening torque**


<b>Model code</b>	<b>Torque</b>	<b>Bolts</b>
EWP-038B/-080C/-130D/-270E	19.12 lb-in (2.16 N•m)	M4 hex. socket head bolt
EWP-410F/-420F	22.57 lb-in (2.55 N•m)	M5 hex. socket head bolt

■ Use of hex wrench instead of a torque wrench

- 1** Fasten the four fixing bolts as tight as can be with the straight long part of a hexagon wrench



- 2** Further turn the cap bolts clockwise 90° with the short part



## Degassing

The gas in the pump and tubing is the obstacle to liquid delivery and needs to be expelled before the pump is started. Especially:

- When the pump starts to run for the first time
- When a flow rate is too low
- After liquid is replaced in a supply tank
- After a long period of stoppage
- After maintenance and inspection are performed

### NOTE


- Both gas and chemical come out together through an air bleed tube. Make sure the end of the tube is located in a supply tank or a container.
- Some chemicals are harmful or attack non-wetted parts. Wash/wipe chemicals off immediately if getting wet.

### ■ EWP VC/VS/VE/PC/PS/PE/TC/SH with the MAN air vent port

#### Points to be checked

- The stroke rate adjusting knob is at the 0% position.
- An air bleed tube is connected to the pump.
- The STOP signal is NOT entered.

Air bleed tube



## 1 Turn on power

The ON LED lights up.


## 2 Set the stroke rate adjustment knob to the 100% position

The pump runs at the maximum speed.

**3 Rotate the adjusting screw two revolutions counterclockwise to open the air vent port**

\*Do not rotate it three revolutions. Otherwise, the adjusting screw may come off with solution spray.

Adjusting screw



**4 Keep the pump running for more than ten minutes for degassing**

**5 Reduce the stroke rate knob to the 0% position**

The pump stops operation.

**6 Rotate the adjusting screw clockwise to close the air vent port**

**7 Check liquid is delivered to the discharge line**

Degassing must be repeated until liquid is outputted from the pump outlet.


**8 Check connections for leakage**

Degassing has now been completed.

## ■ EWP FC with no MAN air vent port

No air vent port is provided to the pump with the FC wet end code. Branch the main flow line (discharge side) to establish an open-ended air vent line.

### 1 Establish an air vent line to your system



### 2 Turn on power

The ON LED lights up.

### 3 Open the air vent valve and set the stroke rate adjustment knob to the 100% position

The pump runs at the maximum speed.

### 4 Keep the pump running for more than ten minutes for degassing

### 5 Reduce the stroke rate knob to the 0% position.

The pump stops operation.

### 6 Close the air vent valve

---

## **7 Check liquid is delivered to the discharge line**

Degassing must be repeated until liquid is outputted from the pump outlet.

---

## **8 Check connections for leakage**

Degassing has now been completed.

---

### ***Flow rate adjustment***

---

*The flow rate can be adjusted by modulating a stroke rate and stroke length. The stroke rate represents the pump speed in %. The stroke rate adjustment is the main way to adjust the flow rate from the pump.*

*The stroke length represents the moving distance of the shaft. The widest moving distance is defined as 100% stroke length. The stroke length adjustment is used for determining the optimal volume pumped per stroke (fine adjustment of the pump flow).*

*First adjust the flow rate with the stroke rate adjustment. Use stroke length adjustment for the range where the stroke rate adjustment can not reach.*

*Note the optimal stroke length changes with operating conditions and liquid characteristics.*

The following procedure is recommended.

---

## **1 With the stroke length 100%, adjust the stroke rate to meet the desired output**

See the "Stroke rate adjustment" section (page 46) and the "Stroke length adjustment" section (page 47) for detail.

---

## **2 Measure the pump output**

---


**3** If the measured output is lower/higher than the desired level, increase/decrease strokes and measure the pump output again

**4** Adjust the stroke length for fine adjustment


**5** Measure the output again to see if the desired output is obtained

### Flow rate, stroke rate and stroke length

**EWP-038**



**EWP-080/-130/-270/-410/-420**




### NOTE

- When back pressure is high, set the stroke length to 100% and adjust the pump flow by modulating the stroke rate.
- When each dose greatly affects a chemical reaction in neutralization or titration application, shorten the stroke length to reduce the volume pumped per stroke. And then tune the stroke rate to finalize.
- When handling liquids that readily generate gas bubbles (sodium hypochlorite or hydrazine solution), set the stroke length to 100% and adjust the pump flow by modulating the stroke rate. Note air lock may occur when the stroke length is set too short.

## ■ Stroke rate adjustment

The stroke rate can be set by the stroke rate adjusting knob from 0 to 100%.



\*The nameplate shows the maximum (100%) output with the full stroke rate and length.

### 1 Turn on power

The ON LED lights up.


### 2 Turn the stroke rate adjusting knob to the desired rate (%)

## ■ Stroke length adjustment


The stroke length can be adjusted when the moving distance of the shaft is changed with the stroke length adjusting knob.

Model	Allowable range
EWP-038	50-100%
EWP-080/-130/-270/-410/-420	40-100%

**EWP-038**



**EWP-080/-130/-270/-410/-420**



## NOTE

- Do not rotate the stroke length adjusting knob when the pump is not running.
- Do not set the stroke length out of the allowable range where the output capacity is not assured.


**1**

### Turn on power

The ON LED lights up.

**2**

### Rotate the stroke length knob to determine liquid volume per stroke



## ***Before a long period of stoppage (one month or more)***

---

### **Clean wet ends and the inside of tubing:**

- Run the pump with clean water for about 30 minutes to rinse chemicals off from the pump head and piping.

### **Before unplugging the pump:**

- The pump unintentionally starts to run as powered on, discharging liquid. Always reduce the stroke rate knob to the 0% position before unplugging the pump.

### **When the pump does not transfer liquid:**

- Clean the valve sets and remove foreign matters.
- If gas is in the pump head, expel gas and readjust the output capacity. See the "Degassing" section on page 41 and the "Flow rate adjustment" section on page 44 for detail.

## **Operation setting**

### ***Manual operation***

---

*Run or stop the pump with the stroke rate/length knob.*

#### **1 Turn on power**

The ON LED lights up.

#### **2 Turn the stroke rate adjusting knob to the desired rate (%)**

Use the knob scale only for reference. If you need higher accuracy, run the pump in the actual operating condition, use a laboratory beaker or cylinder to correct the liquid from the pump for one minute, and then you will have the actual output capacity of the pump per minute.

#### **3 To stop the pump, reduce the stroke rate knob to the 0% position**

## **EXT operation**

---

The pump operation is controlled by the external signal. First, see page 38 to hardwire the EXT IN terminals with your device (e.g. an analog signal generator or a pulse signal generator).

### ■ Analog proportional control

#### **1 Turn on power**

The ON LED lights up.

#### **2 Turn the stroke rate adjusting knob to the ANA position**

#### **3 Enter the 4-20mA signal and run the pump**

The pump stops as the signal is reduced to 4mA or below.

### ■ Pulse synchronous control

#### **1 Turn on power**

The ON LED lights up.

#### **2 Turn the stroke rate adjusting knob to the PLS position**

#### **3 Enter the 0-6Hz pulse signal and run the pump**

The pump stops as the signal is reduced to 0Hz.

## ***Control functions***

---

### **■ STOP function**

The start/stop of the pump can be controlled by external devices such as a level sensor with a normally-open switch.

# Maintenance

***This section describes troubleshooting, inspection, wear part replacement, exploded views and specifications.***

## **!** Important

- Follow instructions in this manual for replacement of wear parts. Do not disassemble the pump beyond the extent of the instructions.
- Always wear protective clothing such as an eye protection, chemical resistant gloves, a mask and a face shield during disassembly, assembly or maintenance work. The specific solution will dictate the degree of protection. Refer to SDS precautions from the solution supplier.
- Risk of electrical shock. Be sure to turn off power to stop the pump and related devices before service is performed.

## **Before unplugging the pump**

The pump unintentionally starts to run as powered on, discharging liquid. Always reduce the stroke rate knob to the 0% position before unplugging the pump.

## NOTE

- It's not the manufacturer's responsibility for any failure due to corrosion or erosion occurred in your operating condition.
- For the need of repair, contact your distributor of Iwaki or the manufacturer of equipment in which our product is built.
- Be sure to drain chemicals and flush the inside of the pump before return so that a harmful chemical does not spill out in transit.

## Troubleshooting

First check the following points. If the following measures do not help remove problems, contact us or your nearest distributor.

States	Possible causes	Solutions
The pump does not run. (LED does not light.)	Power voltage is too low.	<ul style="list-style-type: none"> <li>Observe the allowable voltage range of 90-264VAC.</li> </ul>
	The pump is not powered.	<ul style="list-style-type: none"> <li>Check the switch if it is installed.</li> <li>Correct wiring.</li> <li>Replace a broken wire to new one.</li> </ul>
Pump does not prime.	Pump is air locked.	<ul style="list-style-type: none"> <li>Prime pump per instructions. See page 41.</li> </ul>
	Air in suction tubing.	<ul style="list-style-type: none"> <li>Reroute suction tubing to eliminate air trap.</li> </ul>
	A valve set is installed upside down.	<ul style="list-style-type: none"> <li>Reinstall the valve set.</li> </ul>
	Valve gasket is missing.	<ul style="list-style-type: none"> <li>Install valve gasket.</li> </ul>
	Foreign matters are stuck in the valve ball in the pump head.	<ul style="list-style-type: none"> <li>Take apart, inspect and clean the valves. Replace as necessary.</li> </ul>
	A valve ball is stuck on a valve seat.	<ul style="list-style-type: none"> <li>Take apart, inspect and clean the valve. Replace as necessary.</li> </ul>
Output fluctuates.	Air is trapped in the pump.	<ul style="list-style-type: none"> <li>Prime pump per instructions. See page 41.</li> </ul>
	Overfeeding	<ul style="list-style-type: none"> <li>Purchase separately and mount the check valve. See page 31.</li> </ul>
	Foreign matters are stuck in the valve ball in the pump head.	<ul style="list-style-type: none"> <li>Take apart, inspect and clean the valves. Replace as necessary.</li> </ul>
	Diaphragm is damaged.	<ul style="list-style-type: none"> <li>Replace diaphragm. See page 61.</li> </ul>
	Pressure fluctuates at an injection point.	<ul style="list-style-type: none"> <li>Maintain a pressure constant at an injection point by optimizing tubing or by relocating the point.</li> </ul>
Liquid leaks.	The fitting, the fitting nut or the air vent body is loose.	<ul style="list-style-type: none"> <li>Retighten them.</li> </ul>
	Pump head is loose.	<ul style="list-style-type: none"> <li>Retighten the pump head bolts. See page 39 for the rated torque.</li> </ul>
	O rings or valve gaskets are missing.	<ul style="list-style-type: none"> <li>Install O rings and valve gaskets in place.</li> </ul>
	Diaphragm is damaged.	<ul style="list-style-type: none"> <li>Replace diaphragm. See page 61.</li> </ul>
	Excessive discharge pressure.	<ul style="list-style-type: none"> <li>Check that the discharge line is not closed.</li> <li>Check if tubing is not clogged.</li> </ul>

## Inspection

Perform daily and periodic inspection to keep pump performance and safety.

### **Daily inspection**

Check the following points. If you notice any abnormal or dangerous conditions, suspend operation immediately and inspect/solve problems. See the troubleshooting section as necessary.

When wear parts come to the life limit, replace them with new ones. Contact us or your nearest distributor for detail.

No.	States	Points to be checked	How to check
1	Pumping	• If liquid is pumped.	Flow meter or visual inspection
		• If the suction and discharge pressure are normal.	Check specifications.
		• If liquid has deteriorated, crystallized or precipitated.	Visual or audio inspection
2	Noise and vibration	• If abnormal noise or vibration occurs. They are signs of abnormal operation.	Visual or audio inspection
3	Air ingress from pump head joints and the suction line	• If pumped liquid includes air bubbles, check the line for leakage and loose connection and retighten as necessary.	Visual or audio inspection

### **Periodic inspection**

Retighten the pump head bolts evenly to the following torque in diagonal order.

\*Head bolts may loosen in operation. How fast the bolts start to loosen is depending on operating conditions.

#### **Tightening torque**

Model code	Torque	Bolts
EWP-038B/-080C/-130D/-270E	19.12 lb-in (2.16 N•m)	M4 hex. socket head bolt
EWP-410F/-420F	22.57 lb-in (2.55 N•m)	M5 hex. socket head bolt

\*A hexagon wrench can be used for a torque wrench. See page 40.

## Wear part replacement

To run the pump for a long period, wear parts need to be replaced periodically. It is recommended that the following parts are always stocked for immediate replacement. Contact us or your nearest distributor for detail.

### ! Precautions

- Solution in the discharge line may be under pressure. Release the pressure from the discharge line before disconnecting plumbing or disassembly of the pump to avoid solution spray.
- Rinse wet ends thoroughly with tap water.
- Each time the pump head is taken apart, replace the diaphragm, O rings, and valve sets with new ones.

### Wear part list

Parts			# of parts	Estimated life
Valve set	VC/VS/VE/PC/ PS/PE/TC	FC	2 sets	8000 hours
Diaphragm			1	
O ring	<p>(except the FC and SH types)</p>		See page 65 to 67.	

\*Wear part duration varies with the pressure, temperature and characteristics of liquid.

\*The estimated life is calculated based on the continuous operation with clean water at ambient temperature.

## ***Before replacement***

---

*First release pressure from the pump head and the discharge line.*

### **1 Stop the pump operation**

### **2 Rotate the adjusting screw two revolutions counterclockwise to open the air vent port**

#### **NOTE**

Do not rotate it three revolutions from the closed position. Or liquid may come out from the adjusting screw.

\*The air vent adjusting screw is NOT provided to the pumps with the FC wet end code. Establish an air vent line with an air vent valve and adjust the valve manually to expel gas from the pump and system before operation (see the sketch on page 43 as well.). In the case the air vent line is unable to be built, you have no choice but to remove the discharge line while it is under pressure. This is not totally recommended; however, use a cloth around the fitting nut of the check valve several times until it can be a protection against solution spray and the check valve is safely removed from the discharge tube.

### **3 Check the pump head and the discharge line are depressurized**

Liquid pressure is released from the air vent line in the form of solution spray.

#### **NOTE**

If pressurized liquid is not expelled, run the pump with an opened air vent line until pressure is removed.

## ***Valve set replacement***

---

### **■ Discharge valve set disassembly/assembly**

#### **Necessary tools**


- An 1.5" (38mm) or wider adjustable wrench
- A pair of tweezers

\*Unfix the pump base before disassembly.


**1 Remove the fitting nut, the discharge tube, and the air bleed tube**

**NOTE**


Rinse chemicals or crystals off the parts as necessary.



**2 Turn the lock nut counterclockwise and remove the air vent body A**



**3 Use an adjustable wrench and remove the air vent body B**




**4 Pull out the valve set with a pair of tweezers**

**5** Build up the new valve set into the pump head and hand-tighten the air vent body B through the lock nut as far as it will go. Re-tighten the air vent body B by a further 90° with an adjustable wrench

\*There are many small parts in the liquid end. These parts must be installed correctly for proper operation of the pump (no leak or good pump output). Be sure both valve seats are in the same orientation. See the exploded view pages, also.

\*Be sure to fit O rings and gaskets are in place.


\*Keep the valve set clean.




**6** Remount the air vent body A using the lock nut and connect tubes

**EWP-038B/-080C/-130D/-270E/-410F FC**

**1** Remove the pipe



**2** Use an adjustable wrench and remove the fitting



### 3 Pull out the valve set with a pair of tweezers


### 4 Build up the new valve set into the pump head and hand-tighten the fitting as far as it will go. Retighten it by a further 90° with an adjustable wrench

\*There are many small parts in the liquid end. These parts must be installed correctly for proper operation of the pump (no leak or good pump output). Be sure both valve seats are in the same orientation.

See the exploded view pages, also.

\*Be sure to fit gaskets are in place.


\*Keep the valve set clean.




### 5 Remount the pipe

## EWP-038B/-080C/-130D/-270E/-410F SH


### 1 Remove the discharge pipe and the air bleed tube



### 2 Use an adjustable wrench to remove the lock nut and the air vent body A




**3 Use an adjustable wrench and remove the air vent body B**



**4 Pull out the valve set with a pair of tweezers**

**5 Build up the new valve set into the pump head and hand-tighten the air vent body B through the lock nut as far as it will go. Retighten the air vent body B by a further 90° with an adjustable wrench**

- \*There are many small parts in the liquid end. These parts must be installed correctly for proper operation of the pump (no leak or good pump output). Be sure both valve seats are in the same orientation. See the exploded view pages, also.
- \*Be sure to fit gaskets are in place.
- \*Keep the valve set clean.



**6 Remount the air vent body A using the lock nut and connect the pipe and tube**

## ■ Suction valve set disassembly/assembly


### NOTE

Be careful not to drop the valve set.


### 1 Remove the fitting nut and the suction tube

#### NOTE

Rinse chemicals or crystals off the parts as necessary.



### 2 Remove the fitting




### 3 Pull out the valve set with a pair of tweezers

### 4 Build up the new valve set into the pump head and hand-tighten the air vent body B as far as it will go. Retighten it by a further 90° turn with an adjustable wrench

\*There are many small parts in the liquid end. These parts must be installed correctly for proper operation of the pump (no leak or good pump output). Be sure both valve seats are in the same orientation. See the exploded view pages, also.

\*Be sure to fit O rings (except pumps with SH/FC wet ends) and gaskets in place.

\*Keep the valve set clean.



### 5 Reconnect the suction tube

# Diaphragm replacement

## Necessary tools


- An 1.06" (27mm) or wider adjustable wrench
- A 3mm or 4mm hex wrench (depending on pump size)
- A torque wrench

## NOTE


A few diaphragm spacers may be inserted between the retainer and the shaft for the adjustment of the diaphragm location. Note that the number of diaphragm spacers provided varies at different pumps.

- 1 Run the pump to set the stroke length to 0% and stop afterward**  
Shorten the stroke length to 0% or just to the length that the diaphragm can be removed.


- 2 Loosen the fitting nuts and remove the suction tube, discharge tube, and air bleed tube**




- 3 Remove the pump head with the 3mm or 4mm hex wrench depending on the pump size**



## 4 Unscrew the diaphragm from the shaft




## 5 Slide the retainer and diaphragm spacer(s) onto the screw of the new diaphragm



### NOTE

- Fit the retainer with its round edge to the diaphragm.
- Try not to remove the separate bracket spacer during replacement. If removed inadvertently, catch the mating point with the bracket spacer and push that part into the bracket until it bottoms out.



**6** Screw the new diaphragm into the shaft as far as it will go

**7** Run the pump and set the stroke length to 100%

Stop the pump afterward.

**8** Mount the pump head

Tighten the head bolts diagonally and evenly by the specified torque at each model.

**Tightening torque**

Model code	Torque	Bolts
EWP-038B/-080C/-130D/-270E	19.12 lb-in (2.16 N•m)	M4 hex. sock head bolt
EWP-410F/-420F	22.57 lb-in (2.55 N•m)	M5 hex. sock head bolt


\*A hex wrench can be used for a torque wrench. See page 40.

**9** Reconnect the tubes

## Exploded view

### ***Pump head, Drive unit & Control unit***


*Do not disassemble the pump beyond the description in this manual.*



\*Wet end materials and their sizes differ with models.

# Pump head


## ■ EWP-038B/-130D/-270E/-410F/-420F VC/VS/VE/PC/PS/PE/TC



No.	Part names	# of parts
1	Pump head	1
3	Fitting	1
4	Fitting nut	3
5	Air vent body B	1
6	Lock nut	1
7	Diaphragm	1
9	Retainer	1
10	Air vent body A	1
11	Valve guide	4
12	Valve seat	4
13	Valve	4
14	Valve gasket	2
17	O ring	2
18	Diaphragm spacer	*
19	Hex. socket cap bolt [PW•SW]	4
23	Adjusting screw	1
24	Name plate	1
25	O ring	1
26	O ring	1
27	O ring	1
29	Hose stopper	3
30	Hose adaptor	3
31	O ring	3

\*The number of diaphragm spacers varies with pump model.


■ EWP-038B/-080C/-130D/-270E/-410F FC



No.	Part names	# of parts
1	Pump head	1
3	Fitting	2
4	Coupling Nut	2
7	Diaphragm	1
9	Retainer	1
11	Valve guide	4
12	Valve seat	4
13	Valve	4
14	Valve gasket	6
17	Gasket	2
18	Diaphragm spacer	*
19	Hex. socket cap bolt [PW•SW]	4

\*The number of diaphragm spacers varies with pump model.

■ EWP-038B/-080C/-130D/-270E/-410F SH



No.	Part names	# of parts
1	Pump head	1
3	Fitting	1
7	Diaphragm	1
9	Retainer	1
11	Valve guide	4
12	Valve seat	4
13	Valve	4
14	Valve gasket B	2
18	Diaphragm spacer	*
19	Hex. socket cap bolt	4
20	Spring washer	4
29	Valve gasket A	8
37	Adjusting screw	1
38	Seal nut	1
39	Seal ring	1
40	Seat	1
41	Seat ring	1
51	Air vent body A	1
52	Gasket	1
53	Air vent body B	1
54	Lock nut	1
55	Male connector	1

\*The number of diaphragm spacers varies with pump model.

## Specifications

Information in this section is subject to change without notice.

### ■ Pump unit

Model code	Max. output capacity GPH (mL/min)	Max. rated discharge pressure PSI (MPa)	Stroke length % (mm)	Stroke rate % (spm)	Average power cons. W	Average current A	Weight lbs (kg)
EWP-025A	0.602 (38)	175 (1.2)	**20-100 (0.5-1.25)	0-100 (0-360)	13	0.8	5.07 (2.3)** <sup>3</sup>
EWP-045B	0.7 (45)	145.0 (1.0)					
EWP-075C	1.2 (75)	105 (0.7)					
EWP-125D	2.0 (125)	60 (0.4)					
EWP-265E	4.2 (265)	30 (0.2)			23	1.1	
EWP-080C	1.27 (80)	145.0 (1.0)					
EWP-130D	2.06 (130)	101.5 (0.7)					
EWP-270E	4.28 (270)	50.8 (0.35)					
EWP-420F* <sup>1</sup>	6.50 (410)	29.0 (0.2)					
EWP-420F* <sup>2</sup>	6.66 (420)						

\*Maximum output capacity is rated with clean water at ambient temperature at maximum discharge pressure (also, stroke length 100%, at 360spm and rated voltage). Output may increase as pressure decreases.

\*Allowable room temperature: 32-104°F (0-40°C)

\*Allowable liquid temperature: 32-104°F (0-40°C) for the pumps with VC/VS/VE wet ends  
(32-140°F or 0-60°C for the PC/PS/PE/TC/FC/SH wet ends)

\*Allowable ambient humidity: 30-90%RH (non-condensing)

\*Allowable power voltage deviation: ±10% of the rated voltage

\*Maximum altitude: 6562ft (2000m)

\*Pollution degree: 2

\*Maximum noise level: 70dB at 1m (A scale)

\*<sup>1</sup> The EWP-420F with the TC/TA/FC/SH wet ends

\*<sup>2</sup> The EWP-420F with the VC/VF/VE/PC/PA/PE wet ends

\*<sup>3</sup> The EWP with the SH wet end is 9.7lbs (4.4kg).

\*<sup>4</sup> Stroke length is adjustable from 20-100%, but most accurate 50-100%

## ■ Control unit

<b>Control modes</b>	MAN (Manual)	0-100% (0-360spm)
	ANA	4-20mA in proportion to 0-360spm
	PLS.V	0-6Hz in synchronous with 0-360spm
<b>Front panel</b>	ON LED	Blinks green synchronously with strokes when the pump is running.
	STOP LED	Lights red when the STOP signal is input.
<b>Control functions</b>	STOP	Pump stops when the STOP signal is input.*1
<b>Input</b>	STOP	Dry contact or Open collector*1
	Analog	0-20mADC (input resistance 220Ω)
	Pulse	Dry contact or Open collector*1, UP to 6Hz (with the pulse ON time 5msec or longer)
<b>Power voltage</b>	100-240VAC*2	

\*1 The maximum applied voltage to the contact is 5VDC at 1.0mA. The minimum application load of the relay or switch should be 1mA or below.

\*2 Observe the allowable power voltage range of 90-264VAC. Or failure may result.

## ■ Power cable


<b>Wire size (Cross section area)</b>	18 AWG (0.824 mm <sup>2</sup> ) 3-conductor	
<b>Length</b>	75.74" (inch)	
<b>Cable type/standard</b>	SJTW	
<b>Plug end</b>	US	NEMA 5-15P (115V)
	UH	NEMA 6-15P (230V)

## ■ Pump color

Blue	Munsell color system 7.5PB 3/8
------	--------------------------------

# Outer dimensions

## ■ EWP-038B/-080C/-130D/-270E/-410F/-420F VC/VS/VE/PC/PS/PE/TC




### Dimensions in inches (mm)

Pump unit	A	B	C	D	E	F
<b>038B</b>	6.69" (170)	1.85" (47)	1.30" (33)	0.79" (20)	6.26" (159)	7.64" (194)
<b>080C</b>						
<b>130D</b>						
<b>270E</b>	6.77" (172)	1.37" (35)	0.24" (6)	6.77" (172)	8.15" (207)	
<b>410F/420F</b>				6.73" (171)	8.11" (206)	

\*The pump with the 09/10 tube-size code has the different dimension C and E. Contact us for more information.


■ EWP-038B/-080C/-130D/-270E/-410F FC



Dimensions in inches (mm)

Pump unit	A	B	C	D	E
<b>038B</b>	6.69"	0.51"	1.30"	1.38"	6.14"
<b>080C</b>	(170)	(13)	(33)	(35)	(156)
<b>130D</b>					
<b>270E</b>	6.77"	0.63"	1.38"	0.75"	6.81"
<b>410F</b>	(172)	(16)	(35)	(19)	(173)

■ EWP-038B/-080C/-130D/-270E/-410F SH




Dimensions in inches (mm)

Pump unit	A	B	C	D	E	F
<b>038B</b>	6.65" (169)	0.59" (15)	1.26" (32)	1.58" (40)	5.94" (151)	7.76" (197)
<b>080C</b>						
<b>130D</b>						
<b>270E</b>	6.73" (171)	0.59" (15)	1.34" (34)	1.18" (30)	6.42" (163)	8.23" (209)
<b>410F</b>				1.06" (27)	6.50" (165)	8.31" (211)









Order Online: [www.PumpCatalog.com](http://www.PumpCatalog.com)



<https://www.iwakipumps.jp>  
IWAKI CO.,LTD. 6-6 Kanda-Sudacho 2-chome Chiyoda-ku Tokyo 101-8558 Japan  
TEL: +81 3 3254 2935 FAX: +81 3 3252 8892

**European Headquarter** / IWAKI Europe GmbH  
TEL: +49 2154 9254 0 FAX: +49 2154 9254 48

**Germany** / IWAKI Europe GmbH  
TEL: +49 2154 9254 50 FAX: +49 2154 9254 55

**The Netherlands** / IWAKI Europe GmbH (Netherlands Branch)  
TEL: +31 74 2420011 FAX: +49 2154 9254 48

**Italy** / IWAKI Europe GmbH (Italy Branch)  
TEL: +39 0445 561219 FAX: +39 0445 569088

**Spain** / IWAKI Europe GmbH (Spain Branch)  
TEL/FAX: +34 934 741 638

**Poland** / IWAKI Europe GmbH (East Europe Branch)  
TEL: +48 12 347 0755 FAX: +48 12 347 0900

**Denmark** / IWAKI Nordic A/S  
TEL: +45 48 242345

**Finland** / IWAKI Suomi Oy  
TEL: +358 10 201 0490

**Norway** / IWAKI Norge AS  
TEL: +47 23 38 49 00

**Sweden** / IWAKI Sverige AB  
TEL: +46 8 511 72900

**Belgium** / IWAKI Belgium N.V.  
TEL: +32 13 670200 FAX: +32 13 672030

**France** / IWAKI France S.A.  
TEL: +33 1 69 63 33 70 FAX: +33 1 64 49 92 73

**U.S.A.** / IWAKI America Inc.  
TEL: +1 508 429 1440 FAX: +1 508 429 1386

**Brazil** / IWAKI Do Brasil Comercio De Bombas Hidraulicas LTDA.  
TEL/FAX: +55 19 3244 5900

**China (Shanghai)** / IWAKI Pumps (Shanghai) Co., Ltd.  
TEL: +86 21 6272 7502 FAX: +86 21 6272 6929

**China (Hong Kong)** / IWAKI Pumps Co., Ltd.  
TEL: +852 2607 1168 FAX: +852 2607 1000

**China (Guangzhou)** / GFTZ IWAKI Engineering & Trading Co., Ltd.  
TEL: +86 20 84350603 FAX: +86 20 84359181

**China (Shenzhen)** / IWAKI Pumps (Shenzhen) Co., Ltd.  
TEL: +86 0755 8656 3696

**Singapore** / IWAKI Singapore Pte Ltd.  
TEL: +65 6316 2028 FAX: +65 6316 3221

**Indonesia** / IWAKI Singapore Pte Ltd. (Indonesia Office)  
TEL: +62 21 6906606 FAX: +62 21 6906612

**Malaysia** / IWAKIm SDN. BHD.  
TEL: +60 3 7803 8807 FAX: +60 3 7803 4800

**Korea** / IWAKI Korea Co., Ltd.  
TEL: +82 2 6238 4800 FAX: +82 2 6238 4801

**Taiwan** / IWAKI Pumps Taiwan Co., Ltd.  
TEL: +886 2 8227 6900 FAX: +886 2 8227 6818

**Thailand** / IWAKI (Thailand) Co., Ltd.  
TEL: +66 2 322 2471 FAX: +66 2 322 2477

**Australia** / IWAKI Pumps Australia Pty Ltd.  
TEL: +61 2 9899 2411 FAX: +61 2 9899 2421