

PENTEK®

Important: Please Read This Notice!

P20-132 is installed on the motor and is used with these pumps:

- Berkeley®
- BK-Series
- BKS-Series
- Myers® Predator™ < 25 GPM
- Myers® Rustler™
- SK-Series
- SKS-Series
- Sta-Rite®

For All Other Pumps, remove P20-132 and install A90055C.

See reverse side for installation instructions



Part No. P20-132



Part No. A90055C

Sand Boot P20-132 Installation:



Install the sand boot, **short end first**. Push it down until it seats against the washer.

NOTE: Install the motor gasket and the sand boot or slinger before installing the liquid end on the motor.

To Motor End



Part No. P20-132

Liquid End Brand	Series	Sand Boot
Berkeley	5 thru 50gpm	P20-132
	70gpm	P69-4
	90gpm	A90055C
Sta-Rite	5 thru 50gpm	P20-132
	70gpm	P69-4
	90gpm	A90055C
Myers	Rustler	P20-132
	Predator 5 thru 20 gpm	
	Predator 25 gpm	A90055C
	S-Series	
	Ranger	
Aermotor	All	

Motors less than and equal to 2HP are supplied with P20-132 installed. The A90055C is included in the motor carton.

Sand Slinger A90055C Installation:



Install the conical sand slinger on the motor as shown (big end down).

To Liquid End



Part No. A90055C